


How to disable the battery saver?

ONE PLUS

OXYGEN OS 10




STEP n°1




Tap on **phone settings**

STEP n°2




← Select **Apps & notifications**

STEP n°3




Select **See all apps**

STEP n°4




Tap on **Your App**

STEP n°5



Click on **Advanced**



STEP n°6




Click on **Battery optimisation**

STEP n°7

Select **Don't optimise**





STEP n°8




Go back to the phone settings and select **Battery**

STEP n°9

To avoid battery optimization, make sure that the **Battery Saver** is off






STEP n°10

Return to the menu **Apps & notifications**



Select **Special app access**




STEP n°11




Click on **Battery optimisation**

STEP n°12



Click on ...



STEP n°13

Click on **Advanced optimisation**

STEP n°14

To prevent battery optimization, deactivate the **Adaptive Battery**

