
How to disable the battery saver?

ONE PLUS

OXYGEN OS 12





Tap on phone settings



Settings

- A Password & security
- Privacy
- Safety & emergency
- Battery
- ₩ Apps
- (Location
- Special features
- Digital Wellbeing & parental controls
- System settings
- About device
- Users & accounts




19:25	ı
← Apps	
App management	
Default apps	
Disabled apps	
Special app access	
Auto launch	
Display over other apps	
App cloner Some apps can be cloned. The cloned app will appear on the Home screen and can run at the same time as to original app.	he
Split screen	
You might be looking for:	
App lock	




Select App management

19:26 ← App management A Your App









Allow background activity and auto-launch




Settings

- A Password & security
- Privacy
- Safety & emergency
- Battery
- ₩ Apps
- O Location
- Special features
- Digital Wellbeing & parental controls
- : System settings
- About device
- Users & accounts

STEP n°7




Go back to the parameters and select **Battery** on the phone's settings






Click on Power saving mode



Allow Background activity and auto launch



Go back to the Batterie menu



Select Advanced settings

19:27





High performance mode

The system always operates in a high performance mode, but it will increase extra power consumption.



Optimize battery use

Automatically optimize apps that are draining battery in the background.

Sleep standby optimization

Your device consumes less power and reduces notifications when you are asleep.



Optimized night charging

To reduce battery aging, your device learns from your daily charging routine so it can control the charging speed at night and avoid overcharging.




Wireless charging settings


STEP n°11




Select Optimize battery use









Choose Don't optimise